

Leaf protection systems for Downspout

make it easy...



Wire downspout strainer



With a wire downspout strainer, the drain of the gutter or the downspout remains free of leaves, reducing the possibility of blockages. The wire downspout strainer is inserted into the gutter mounting socket.

Article number

DN 60 DN 80	galvanized steel 42 600 36 89 0723 42 600 36 89 0556	DN 100	galvanized steel 42 600 36 89 7548	
------------------------------	---	---------------	--	--

Leaf Trap Ratio



The Leaf Trap Ratio consists of a leaf basket that is hung in the tube and a sliding piece that allows access to the basket - making cleaning easy. In addition, the Leaf Trap Ratio can also be used as an inspection opening.

Article number

DN 100	Zinc 40 55 66 400 1043	Length in mm 300
---------------	----------------------------------	----------------------------

Optimal use of rainwater

Downspout cleanout type 1 + hose connection



The Downspout cleanout type 1 for installation in the downpipe is used to collect rainwater. The rainwater collector has an overflow stop, excess water is automatically fed back into the downpipe. The connection to the water butt is made via the hose connection set (spiral hose + water butt bushing).

Article number

DN 60 DN 80	Zinc 40 55 66 401 3145 42 600 36 89 3854	DN 87 DN 100	Zinc 42 600 36 89 4301 42 600 36 89 3847	Hose connection 42 600 36 89 3861
------------------------------	---	-------------------------------	---	---