



D	OW	/ns	sp	0	ut	b	ra	Cl	(e	t
---	----	-----	----	---	----	---	----	----	----	---



The downspout bracket is professionally fastened to the wall with the downpipe clamp. One pipe clamp is required for each running meter of downpipe.

Attachment with collar screw

Length in mm 185

Article number

Steel - anthracite DN 76 40 55 66 401 3671

Steel - grwy 40 55 66 401 3688

Steel - brown 40 55 66 401 3695

Steel - white 40 55 66 401 3701

Downspout Y-pipe



The downspout Y-pipe provides a connection of side pipes from the roof to the downspout.

Angle: 87,5°

a / b in mm 295 / 145

Article number

DN 76 / DN 76

PVC - anthracite 40 55 66 401 3718

PVC - grey 40 55 66 401 3725 **PVC - brown** 40 55 66 401 3732

PVC - white 40 55 66 401 3749

Downspout cleanout



The downspout cleanout for installation in the downspout is used to collect rainwater. The sieve serves as a leaf catcher for the downspout and should be removed in winter to avoid the risk of icing. There are special outlet extensions for the downspout cleanout, which are to be attached using a plug connection.

a / b in mm 400 / 200

Article number

	PVC - anthracite	PVC - grey	PVC - brown	PVC - white
DN 76	40 55 66 401 3756	40 55 66 401 3763	40 55 66 401 3770	40 55 66 401 3787